NETIO-230C/CS

Quick installation guide

Thank you for purchasing the KOUKAAM product. Before usage, please, carefully read this Quick Installation Guide and Operating Instructions you can find on the CD which is included in the pack. You thus avoid incorrect installation or incorrect usage of the equipment.
Carefully read the following warning.

Important notice

1. The equipment that you have purchased operates under a certain voltage. Incorrect manipulation with the equipment may result in damage to the equipment or injury to the person handling it.
2. The manufacturer is not liable for potential damage caused by incorrect usage or location of the equipment in an unsuitable environment.
3. The equipment is not for outdoor usage.
4. Do not use the equipment in an environment with strong vibrations.
5. Unauthorised modification of this equipment can damage it or cause fire.
6. Prevent contact with fluids; do not expose the equipment to high temperatures.
7. Protect the equipment from falling.
8. Only equipment approved for use in electricity network may be connected.
9. If the equipment malfunctions, disconnect it from the electric power supply and contact your vendor.

Package contents

1. NETIO-230C/CS
2. Network patchcord
3. Power cable
4. Extension cable
5. Installation CD
6. Quick Installation Guide

Front view

1. LED diodes
2. Buttons
3. Serial port
4. RJ45-Socket / Ethernet
5. Serial tunnel
   (NETIO 230CS model only)



Back view

1. Main power switch
2. Power inlet
3. Fuse holder
4. Output sockets



Connection

- Connect your NETIO-230C/CS to the computer network (switch, router) using the supplied Ethernet cable with RJ-45 connectors.
- Connect devices that you want to control to outputs (power outlets).
- Connect the NETIO cable plug to the power outlet. Turn the main power switch to ON position (See Back view picture).

Network Search

- Default IP address is **192.168.10.100**. If there is DHCP server in your network, NETIO will acquire IP address automatically.
- For network search and set up of IP address, as the case may be, use the *NetioDiscover* utility, which is on the supplied CD. Use the *Discover* button to search for NETIO devices connected in your network. Use the *Device setup* button to change the network parameters of the device selected from the list. By double clicking on the specific device in the list, you can directly open its web page in your web browser.

First Login

- Input the IP device address that the device obtained from the DHCP server via the NetioDiscover utility into the web browser.
- Enter the user name and password on the login page. Default user name is **admin** and password **admin**. You can later change the password and username in the equipment configuration utility.
- You have just logged in the web interface. The user manual is on the supplied CD.

We believe that you will be satisfied with our product. In case of any questions or comments relating to the functionality of the NETIO product, please do not hesitate to contact us.

The KOUKAAM Team
www.koukaam.se

The manufacturer bears no responsibility for any technical or printing errors and reserves the right to make any changes in the product and in this user manual without prior notice. Any such changes shall be announced via the manufacturer's website www.koukaam.se.
The manufacturer does not provide warranties of any kind whatsoever with regard to any information given in this user manual or any derived warranties regarding product saleability or its fitness for a specific use.
In particular, the manufacturer does not provide any warranties for defects caused by incorrect use of the product, failure to abide by the instructions and recommendations given in the user manual and in the Quick installation guide and for any defects caused by unprofessional activities of third parties outside the manufacturer's authorized service shop.

KOUKAAM a.s.
Kaplanova 2252/8
Prague 4, 148 00
Czech Republic
www.koukaam.se

© 2011 KOUKAAM a.s. All rights reserved.

Koukaam
www.koukaam.se